



09165 RAM PRIMING UNIT

Key	Part #	Description
1	09471	Primer Rod Assemblies (Lg. & Sm.)
2	09111	Shell Holder Spring
3	09175	Ram Priming Body
4	87505	Hex Lock Nut 7/8-14
5	09176	Primer Rod Holder




09495 PRIMER POCKET SWAGER COMBO

Key	Part #	Description
1	09485	Swager Body
2	09486	Swager Rod
2	09498	Swager Rod .223 Rem
3	09604	Lock Ring, 1/4-28
4	09487	Case Stripper
-	09488	Case Stripper Washer (for A-2 Press)
4	09489	Case Stripper for Big Max
4	09490	Case Stripper (for Ammo, Mstr. Single)
5	09483	Swager Head, Large
5	09484	Swager Head, Small
6	87505	Hex Lock Nut, 7/8-14




09580 AUTOMATIC PRIMER FEED COMBO

Key	Part #	Description
1	09598	Body
2	09595	Stop Pin
3	09596	Coil Spring
4	09591	Setscrew, 1/4-28x3/16 CP
5	09581	Primer Tube Assembly, Lg.
5	09582	Primer Tube Assembly, Sm.
6	09599	Primer Tube Cotter Pin
7	09585	Primer Pickup, Lg.
7	09586	Primer Pickup, Sm.
8	09594	Body Assembly (includes part #s 1,2,3,4)



09512 STANDARD PRIMING TOOL

Key	Part #	Description
1	09513	Main Body Casting
2	09111	Spring Clip
4	09514	Handle Cam Assembly
5	09518	Handle Cam Pin
6	09519	Shell Holder Adaptor
7	09520	Coil Spring
8	09591	Setscrew, 1/4-28x3/16 CP
9	09522	Adaptor Sleeve
10	09471	Primer Rod Assembly (Lg. & Sm.)



09525 BERDAN DECAPPING TOOL

Key	Part #	Description
1	09526	Handle
2	09527	Head
3	09528	Decapping Pin
4	09532	Case Holder
5	09533	Head Cross Pin
6	09534	Allen Wrench 5/64
7	09509	Setscrew 8/32 x 1/4 (2)

