




90200 HAND PRIMING TOOL


| Key | Part # | Description |
|-----|---------|-------------------------------|
| 1 | 7-90201 | Hand Priming Tool Body |
| 2 | 7-90202 | Handle |
| 3 | 1-90203 | Primer Feed, Large Right Half |
| 3 | 1-90205 | Primer Feed, Small Right Half |
| 4 | 1-90204 | Primer Feed, Large Left Half |
| 4 | 1-90206 | Primer Feed, Small Left Half |
| 5 | 1-90207 | Primer Tray Lid |
| 6 | 1-90208 | Primer Tray |
| 7 | 7-90220 | Pivot Link Assembly |
| 8 | 7-90211 | Safety Gate Screw |
| 9 | 7-90212 | Handle Pin |
| 10 | 7-90213 | Primer Rod, Small |
| 10 | 7-90214 | Primer Rod, Large |
| 11 | 7-90215 | Link Follower |
| 12 | 1-90221 | Safety Gate Assembly |
| 13 | 1-90217 | Return Spring |
| 14 | 187549 | Retaining Ring (2) External |



09550 UNIVERSAL PRIMER ARM-2

| Key | Part # | Description |
|-----|--------|-----------------------------|
| 1 | ◆ | Body |
| 2 | 09552 | Plug & Sleeve & Spring, Lg. |
| 2 | 09553 | Plug & Sleeve & Spring, Sm. |


◆ Not Available Separately



09450 POSI-PRIME HAND PRIMING TOOL

| Key | Part # | Description |
|-----|--------|---------------------------------|
| 1 | ◆ | Hand Priming Tool Body Assembly |
| 2 | 09111 | Shell Holder Ram Clip Spring |
| 3 | 09549 | Primer Rod Assembly (Lg. & Sm.) |

◆ Not Available Separately



NOTE: This product has been discontinued and is no longer available. See replacement parts are available. Call or write RCBS Customer Service for information.

09460 AUTOMATIC PRIMING TOOL

| Key | Part # | Description |
|-----|--------|---------------------------------|
| 1 | 09462 | Main Body Casting |
| 2 | 09472 | Automatic Primer Feed Arm |
| 3 | 09595 | Stop Pin |
| 4 | 09596 | Coil Spring |
| 5 | 09591 | Setserew, 1/4-28 x 3/16 CP |
| 6 | 09464 | Shoulder Bolt 7/16 |
| 7 | 09473 | Handle |
| 9 | 09264 | Handle Grip |
| 10 | 09467 | Setserew, 5/16-18 x 3/8 HD |
| 11 | 09468 | Main Ram |
| 12 | 09471 | Primer Rod Assembly (Lg. & Sm.) |
| 13 | 09111 | Spring Clip |
| 14 | 09581 | Primer Tube Assembly, Large |
| 14 | 09582 | Primer Tube Assembly, Small |
| 15 | 09599 | Primer Tube Cotter Pin |
| 16 | 09465 | Return Spring |

